

4 EASY STEPS

To Check Your Oil

1

Make sure car is on a flat surface

2

Pop Hood of car (located by the steering wheel) and locate where the oil is in your engine.

3

Pull out the oil dipstick from the engine. This should lift straight out, labeled Engine oil and is often a bright colour with a handle like top. Take a napkin or cloth and wipe oil off of stick.

4

Place stick back into engine and put out again. There will be two marks on the end of your dipstick. The oil should have coated your stick between those two lines. Ideally, it should touch the highest line. If its below the lowest or you can't see it at all, TOP IT UP ASAP!